

Proton Board-Level Testing: Achieving Limited Radiation Assurance with Minimal Testing

Steven M. Guertin and Andrew C. Daniel

steven.m.guertin@jpl.nasa.gov

818-321-5337

Jet Propulsion Laboratory / California Institute of Technology

Acknowledgment:

This work was sponsored by:


The NASA Electronic Parts and Packaging Program (NEPP)

Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not constitute or imply its endorsement by the United States Government or the Jet Propulsion Laboratory, California Institute of Technology.

© 2018 California Institute of Technology. Government sponsorship acknowledged.



Is This Assurance Engineering?





Outline

- **The best scenario**
- **What is board-level testing with protons?**
- **What are the problems?**
- **It has be useful... why?**
- **Test planning**
- **Test preparation**
- **Test execution**
- **Test interpretation**
- **Lessons Learned**
- **Summary**




Best Use(s) of Proton Board Testing

- **Remaining risk is within the mission risk profile**
- **When you are going to LEO**
- **You have exact copies of the flight board**
- **Your system has ~ 100 components**
- **Even then, you get limited assurance**
 - **No information on worst-case SEE if parameters change**
 - **You only get system failure rates of about 0.01/system-day – provided nothing fails during the proton test**
- **It's going to work best when the environment is weak**
 - **Fails to effectively test higher LET portions of space spectrum**



NEPP Guideline

- People are testing boards, boxes, and other assemblies with only protons
- This is of ... limited value
- And there are significant ways that tests can be of even less value
- NEPP is developing a proton board-level testing guideline to help with this problem




iPad irradiation at UC Davis

- See also the NEPP low-energy proton test guideline:
http://radhome.gsfc.nasa.gov/radhome/papers/MRQW2012_Pellis_h.pdf



Is a Board-Level Test going to Help?



VS...



- Board level tests have many issues...
- Would you be better off guessing?



And When There's a Failure?




- Do you know anything about what happened?
- Probably it will just be called an “anomaly”...
- Is the on-orbit failure worth the money you saved?



The Hard Truth

- **When I first started looking at this...**
- **It looked a bit like a war**
 - Red light people were saying it was useless – Literally you're better off not doing it because it is misleading
 - Green light people were saying it could be used to assure multi-year missions
- **But, as I looked closer...**
- **Red/Orange light vs Yellow light.**
 - The method does not assure, but it can give you an approximate failure rate.
 - How high should that failure rate be for a mission to fly?
- **But some new groups on the stage were seeing the green light...**
- **This is more of a system validation/risk evaluation approach – gives a warm and fuzzy feeling**



Board Level Testing Done Right

- **If you have the right combination of**
 - Mild environment
 - Short duration
 - Willingness to accept risk
- **Typical environments where it might be good**
 - Minimal high LET particles (ideally, very little GCR)
 - Proton-dominated, or weak radiation environment
 - LEO (especially equatorial – note that ISS is not equatorial)
 - MEO (low-LET dominated, but very high radiation)
 - Mars surface
 - Other magnetically-shielded locations
- **Mission profiles**
 - Very short (for example, approach to ISS ~ 10 minutes)
 - High risk tolerance
 - High redundancy, active mitigation



Board Level Testing Done Right

- For radiation hardness assurance, is there a simple and cheap way to:
 - Do single-event effects testing of a flight board/assembly, all at once?
 - And simulate much of the space environment at once?
 - Sort of, but you may miss a lot...





- What do you do?
 - Test with high energy (~200 MeV) protons. (Next slide...)
 - You can test multiple boards simultaneously
 - Multiple energies is best for assurance (but you need 0 events)
- How good is it?
 - Questionable – worse if done wrong. (Rest of the talk.)
 - But it does give good fault injection, similar to using neutrons to inject errors at the board level.



Space vs. Protons

- Protons generate “higher LETs” through secondaries provided by the target.
- Basic comparison is to just look at the LET generated by proton secondaries.
 - Hiemstra, and also recent work by Ladbury
- The basic comparison suggests that LETs as high as $12 \text{ MeV-cm}^2/\text{mg}$ are tested.
 - $\sim 20 \text{ particles/cm}^2\text{-year}$ are above this in ISS orbit.
- But this is misleading...





But Even That's Not Right

- The Sensitive Volume (SV) model says that the critical value for ion SEE is Q_c

$$Q_c = \int C * LET(x) dx$$


- Proton secondaries have very limited range – usually $< 20 \mu\text{m}$
 - At best, this limits the integral.
 - This is critical for SEE types with deep charge collection, like SEL



Protons Have Limitations

- In a $2\mu\text{m}$ sensitive depth...
 - $1 \times 10^{10}/\text{cm}^2$ 200 MeV Protons
 - More protons can be used
- Proton recoils give energy depositions similar to heavy ions
 - But leave high energy deposition gap
 - More protons weakly affect the gap region
- But not all SEE modes are this shallow
 - More later

Foster, IEEE TNS, 2008 –
energy deposition in $2\mu\text{m}$






Protons Have Limitations

- In a $2\mu\text{m}$ sensitive depth...
 - $1 \times 10^{10}/\text{cm}^2$ 200 MeV Protons
 - More protons can be used
- Proton recoils give energy depositions similar to heavy ions
 - But leave high energy deposition gap
 - More protons weakly affect the gap region
- But not all SEE modes are this shallow
 - More later

Foster, IEEE TNS, 2008 –
energy deposition in $2\mu\text{m}$



Events during proton testing

Events during 10 year ISS mission

Gap


Similar to LET 14 – but not actually LET




Why 200 MeV?

- Protons are a proxy for heavy ions because their secondaries give LETs in excess 14 MeV-cm²/mg.
- The higher the energy of the beam, the higher the energy (not LET) of the secondaries.
 - Total deposited energy is higher, so they are more space-like.
 - Actual energies form a distribution...
 - Increased range improves damaging SEE effectiveness
 - Higher LETs in space are mostly Fe – missing in proton secondaries...
 - Are there enough secondaries to get coverage/assurance?
- But > 200 MeV is not readily available, and doesn't really improve things much.
 - Max LET is still only around 14 MeV-cm²/mg
 - Overall range is better
 - Options like Los Alamos (800 MeV), TRIUMF (500 MeV), CERN, and PSI exist.

Hiemstra, 2003 – for 500 MeV protons





200 MeV Is a Sweet-Spot, but...

- It is good for proton secondaries.
- Higher proton energy also reduces dose.
- It puts SEE test facilities in-line with medical facilities.




- Dozens of facilities...



There Are Many Potential Issues

- Test results are not well-defined, because system size can be arbitrary
 - Assume the test results in a system rate of R ...
- Questions arise throughout the test planning and execution...





Scorecard



- The proton board-level testing method has a history of success
 - But it is not supported by solid engineering or physics
-
- Have previous practitioners have been conservative in using the approach?
 - Maybe
 - Have we been lucky that systems worked well?
 - Probably. Might even be “accidentally” mitigating damage
 - NASA has only used this in non-critical systems
 - Have some failures not been reported?
 - Difficult to say on the NASA side – probably logged, but not necessarily brought to attention of radiation people
 - Suspect situation is worse in most other organizations




Pragmatic Approach – Data Driven

- **If you don't use the hard engineering and science limits, which are terrible...**
 - The other approach is to be pragmatic – see how it does
- **What type of data do you need to support or refute the test approach?**
 - Heavy ion data with LETs between 2 and 15 MeV-cm²/mg
 - & Proton data
 - The critical dataset is devices with:
 - Proton failures that can be correlated to heavy ion failures
 - Lack of proton failures but with heavy ion failures with an established space rate
 - No proton or heavy ion failures



Pragmatism – The Danger

- **When the method has been used**
 - JSC has used for low criticality items on the ISS
 - Not mission critical, and astronauts can disconnect
 - Has been OK? Has it?
 - These are low budget programs... other unhandled failure elements could be there
 - Determining failure root cause can be difficult




- Or have failures not been reported?
 - It can be expensive to figure out... maybe just cut the loss?
- **How would you show it is bad?**
 - Distribution of parts you might test vs proton and heavy ion data.
 - But nobody collects this data



Example of a Bad Part

- How bad can the “gap” be – what’s missed by a $1 \times 10^{10}/\text{cm}^2$ proton test
- One example bad part is the HM65162 (1985) SRAM



- Has SEL at very low LET
 - Energy cutoff discussed above suggests SEL should be seen
 - Actually has ~40% of no SEL in $1 \times 10^{10}/\text{cm}^2$ protons
 - Since threshold is low, more protons gives higher chance of seeing SEL. $1 \times 10^{11}/\text{cm}^2$ @ 200 MeV (6 krad[Si]) gives >99%
 - But here we know the curve...
- ISS SEL rate is about 0.01/device-day
- Similar observation - NEC4464



Nobody Takes this Data

- **If you take heavy ion data first**
 - The part would have to fail with an LET below 8 MeV-cm²/mg or have no failures to be of interest
 - If the program is serious enough to take heavy ion data:
 - Failures mean part is eliminated, proton data is not needed
 - No failures mean proton data is not needed
 - Special case: The part fails under heavy ions but the project is desperate and wants to know how bad it is...
 - Remove conservatism in bound for proton sensitivity
- **If you take proton data first**
 - Program is interested in things like displacement damage
 - Program is just testing for protons – no heavy ion data will be taken
 - Special case: Maybe it was just a timing thing, as part of a complete dataset...



Test Planning - 1

- Test a copy of the flight board – same parts – manufacturer and part number should match.
 - “good engineering” says they really need to be the same, but people are often trying to justify “similar devices”
 - SPARTAN flights actually flew irradiated hardware (RADECS '98) – **Not Recommended**
 - Reserve beam time 8 months ahead of time. Proton beam time is difficult to schedule.
-
- Use beam energy of at least 190 MeV in order to keep TID on articles below 1 krad(Si) when irradiating to $1 \times 10^{10}/\text{cm}^2$.
 - Determine if $1 \times 10^{11}/\text{cm}^2$ may be better for your situation (only buys about 3x better results for SEL, SEGR, SEB)




Test Planning - 2

- **You can only reliably achieve 0.01-0.003 damaging events per system day in LEO – if this is not good enough, heavy ions are required. (NEPP Board Proton Testing Book of Knowledge)**
 - Higher assurance claims are not grounded in physics or engineering, but may “seem” to work.
- **Test early in the cycle, so the results can be used. Don’t just hope the results will be ok.**
 - Normal RHA flow, but often missed for this approach.



Test Planning - 3

- There are some parts with failure rates around 0.1/device-day in ISS orbit. You're here without test data.
- Test boards must use the same devices as flight units
- With proton testing, $1e10/cm^2$ results in DSEE rates around 0.01/device-day
 - $1e11/cm^2$ improves this, but hard numbers are limited
- Must consider exposure level and SEE types
- If possible plan to use two energies to enable use of Bendel 2-parameter



—Ladbury, IEEE TNS, 2015

Equivalent LET = Energy / ($\rho \cdot d_{SV}$)

Max Equivalent LET requires 2.3 recoils



Facilities

- **For proton-only testing, 200 MeV is heavily desired. (Required to meet claims given in guideline.)**

Facility	Location	Type	Energy, MeV	Availability
Tri-University Meson Facility	Vancouver, CAN	Cyclotron	480	Ok, but 4x/year
Slater Proton Treatment and Research Center at Loma Linda University Medical Center (LLUMC)	Loma Linda, CA	Synchrotron	250	4-8 weeks?
Mass General Francis H. Burr Proton Therapy (MGH)	Boston, MA	Cyclotron	235	Booking 8 months out
NASA Space Radiation Lab (NSRL)	Brookhaven, NY	Synchrotron	2500	Ok, but \$\$

- **Ideally, synchrotrons would be avoided due to beam structure impact on testing**
- **Other proton facilities are available, but require direct communication/discussion for each user**



Test Preparation - 1

- **Contact facility to get details and recommendations for use of the facility.**
- **If possible, perform a walkthrough of the facility a few weeks before the actual test.**
- **Discuss beam parameters with the facility: time and space structure, flux & flux range, etc.**
- **Determine if the facility can accommodate the full size of your hardware.**
- **Hardware usually cannot ship for at least a few days after the test.**
- **Test the full setup (including full cable length) before arriving at the facility.**



Photo: Irradiation of iPad at UC Davis – due to spot size, multiple irradiation sites were necessary.



Test Preparation - 2



- **Test boards/equipment**
 - Remove bulky heatsinks
 - Remove/don't install shielding (we're not testing the shielding predictions)
 - Limit beam exposure of any non-test equipment
- **Work with facility regarding shipping – especially to Canada**
- **During exposure, all items in the beam will be exposed to TID**
 - Generally, TID levels over 3 krad(Si) are likely to cause problems with boards (but it could happen lower) – **Be careful of unit TID limits!**
 - $1 \times 10^{11}/\text{cm}^2$ is the only viable higher proton limit – requires multiple boards
 - This is only about $1 \times 10^5/\text{cm}^2$ recoils – which is not at the level of a viable heavy ion test.

Proton Energy	Dose for $1 \times 10^{10}/\text{cm}^2$	Dose for $1 \times 10^{11}/\text{cm}^2$	Dose for $1 \times 10^{12}/\text{cm}^2$
50 MeV	1.6 krad(Si)	16 krad(Si)	160 krad(Si)
100	0.94	9.4	94
200	0.58	5.8	58
500	0.36	3.6	36



Test Execution - 1

- **Keep a test log including:**
 - run number
 - DUT/UUT identification
 - time, fluence, flux
 - etc...
- **Use cooling fans instead of heatsinks (keep fans out of beam) – if possible**
- **Avoid stacks of 6 or more boards**
- **Test with proton beam normal to the test boards**
 - If boards are mounted 90 degrees to each other, test multiple units with beam normal to the board surfaces
 - If angles are used, multiply the fluence delivered by the cosine of the angle of incidence.
- **Use beam exposures with duration > 60 s, with at least 10 s between events, or consider slowing down the beam.**





Test Execution - 2

- **Verify the beam details by requesting beam diagnostic information from the operator**
 - Radiochromic film, scan information, or other
- **Be cautious about collimation with brass/copper vs. magnetics. Collimators produce neutrons.**
 - Facility may be focused on TID, but you care about neutrons...
- **Ensure the test board(s) are positioned far enough away to expose all electronics.**
- **If multiple boards are used, may want to put Radiochromic film between each unit**
 - But it measures dose, not particle fluence...






Test Execution - 3

In the lab...



- **Verify test equipment to be used on-site**
 - At home & on-location
 - Cables!
 - Shipping damage


At the facility...





Test Execution - 4

- Operational test modes should be considered carefully
 - Test for normal system response (flight-like application) and recovery (if possible stop the beam during recovery)
 - Typically doesn't have good prognostics or diagnostics
 - Designs specifically for an accelerated test (design for test)
 - Identify errors and increase coverage – but requires careful development
- Try to observe as many error modes as possible
 - Strange, rare event types may be dangerous
 - If there is something rare that may cause a big operational problem, it is more important to study than 100s of events that are easily handled
 - But they may be test artifacts
- Test operations should keep in mind the beam structure – i.e. synchrotron vs. cyclotron
 - For static tests, beam structure only really causes problems with figuring out live time.
 - But for dynamic tests, it is important that the test does not alias with the beam delivery...





Finish Up

- **Be prepared to not have your equipment for a couple weeks due to activation**
 - Will be worse with higher energies and higher exposures
 - Shipping regulations vary, discuss with the test facility
- **Ideally, a post-irradiation burn-in may help identify latent damage**
 - You are not instrumented for a real SEL test!
- **All observed error types should be documented before leaving the facility**
- **Obtain test logs, exposure information, and ensure any shipping or facility exit requirements are handled.**






Test Interpretation/Reporting

- It would be great to have a detailed test report, but a simple summary of the test and observations should be a minimum
- If damaging events are **NOT SEEN**, use the following estimations:
 - 0.01 events/system-day for $1 \times 10^{10}/\text{cm}^2$ or
 - 0.003 events/system-day for $1 \times 10^{11}/\text{cm}^2$
- For non-damaging events (transients, bit upsets, etc.)
 - $N * 0.0005$ events/system-day for $1 \times 10^{10}/\text{cm}^2$ where N is the number of observed events.
 - This scales for higher test fluences.
- If damaging events are seen, use the larger of estimates above.



Lesson Learned: Plan for a Failed Test

- **Actually, this seems to be the lesson that is never learned... this happens all the time.**




- **What do you do?**
- **Many programs tell us they have to use it anyways...**
- **But this means you have to know, when planning, how you will handle a failed test.**
 - **Usually programs don't know, but are tolerant of high mission failure probability. Are you?**



Lesson Learned: Be Ready to Use Test Results

- During one board level test, a permanent failure was observed.
- Because the schematics were available, and a radiation expert (familiar with parts list reviews) was on hand...
 - A list of at-risk parts was identified
 - List was narrowed down by circuit implementation
 - Further narrowed down by failure (no power delivered)
- Identified a MOSFET operating at $>80\%$ of rated V_{gs} in the design
 - Recommendation is $< 50\%$
 - Circuit testing showed the MOSFET had failed
- Were able to swap in alternate (with higher V_{gs}) that enabled system to work and not fail in radiation.





Lesson Learned: Flight-Like Operation

- Test approach was to have all board operations cycled through during exposure
 - Complex applications made to target all board operations – multiple applications
- The board was dependent on a commercial PowerPC processor running Linux, with the operations in a test program.
- Actual observations were primarily kernel panics due to unhandled exceptions.
 - No additional value was obtained from different software applications
- None of the special test applications showed SEEs because operating system was primary weak point.
 - The exception that proves the rule - test with flight-like OS
- Lesson: Don't develop a lot of extra test operations outside of flight use
 - At least until you know general behavior



Photo: Efika 400MHz PowerPC SBC



Moving Forward

- **Approach is driven by data on worst parts – is there really enough data yet? Most likely no.**
 - Why would anyone take proton data on a part that is observed to have SEL with an LET of less than 10?
 - Why take heavy ion data in a part that has SEL observed with protons?
 - Can we press people to take this data and build a dataset?
- **Given the inherent limitations of the method, how can we achieve the best results?**
- **Is there a viable way to test to very high fluence?**
 - Generally speaking, we don't think $1 \times 10^{12}/\text{cm}^2$ is viable – especially for assemblies / boards due to dose and # of boards.
 - But these are cheap – many devices could be tested cheaply.
- **Board-level testing provides a means to explore system-level errors due to radiation.**
 - This is becoming very difficult to model from the component level



Summary

- **Proton testing can be used in lieu of normal assurance (including heavy ions) if**
 - Environment is weak (i.e. LEO, ISS, Mars Surface)
 - Mission is short or can handle high risk
 - You are OK with only having a data point on performance and not really achieving hardness assurance.
- **Physics and engineering both suggest fairly high rates for possible damaging SEE**
 - 0.01 to 0.003/system-day for ISS orbit when testing with 1×10^{10} - $1 \times 10^{11}/\text{cm}^2$.
- **To ensure the test method provides results that can be trusted to these levels, we provide recommendations.**
 - Test Planning
 - Test Preparation
 - Test Execution
 - Text Interpretation/Analysis



Acknowledgement

- **Special thank you for many useful discussions with Ray Ladbury and Ken LaBel.**
- **Also thanks to many people who either directly or indirectly influenced how I approached or interpreted this topic.**
- **And special acknowledgement to the commercial entities, CubeSat, and other small satellite groups pushing to re-evaluate these methods.**